



Managing Water Tankers

Know where your water tankers are and monitor rates of water application across your site to ensure optimum asset utilization.

Monitor tank water levels to maximise capacity.

Monitor vehicle speed as well as pitch and roll to ensure safe operation across your site.

Know that the batteries of your vehicles are charged and ready for operation.

The ORB-X1-G includes a GPS and GNSS navigation system to accurately pinpoint location and measure speed.

Use the ORB-X1 current source to measure tank water level with a 4-20mA depth sensor.

Connect a pulse flow sensor to the ORB-X1 frequency input to measure water flow rates.

Use the ORB's integrated accelerometer to measure pitch and roll.

