



Boat Monitor

Peace of mind for boat owners

Receive an alert if your boat leaves the mooring. Track location remotely.

Monitor bilge water levels. Receive alarms if water level rises. Ensure the batteries are changed; receive low battery warnings.

Enable Intruder detection with a switch on the cabin and engine hatch doors.

Monitor wind speed and direction, water temperature and more.

The ORB-X1-G has an integrated GPS for position monitoring.

Use the OB-X1 current source to monitor bilge level with a 4-20mA depth sensor or connect a level-switch to an input.

The ORB-X1 uses very little power and will not drain the battery.

Connect a pulse output wind-speed indicator connected to the frequency input.