



# Solar Installation Monitoring

Monitor the voltages on backup batteries used in remote solar installations.

Optimise the positioning of solar panels to achieve maximum solar energy.

Measure the temperature of solar installations to prevent damage and ensure a maximum lifetime for your equipment.

Receive alerts when capacity falls below required levels.

The ORB-X1 has an extra wide voltage input range and can be powered from and can measure 24V, 48V and 60V solar installations.

Use the ORB-X1 thermocouple input to accurately measure the temperature of your backup batteries.

Receive alerts for over-voltage, over-temperature and under-capacity.